




## VIOLA TABLE LAMP

### PARTS INCLUDED

- (A) Final (1)
- (B) Harp (1)
- (C) Harp Saddle (1)



**IMPORTANT: PLEASE READ**

**IMPORTANT SAFETY FEATURES**

**BULBS**

This fixture has been rated for up to one (1) 8.5-watt maximum Type A dimmable LED bulb (Not included). To avoid the risk of fire, do not exceed the recommended wattage.

**DIMMER SWITCH COMPATIBILITY**

This fixture is dimmer-switch compatible.

**WARNINGS**

All wires are connected. When unpacking, be careful not to pull wires, as damage may result. Do not connect electricity until the fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the light bulb. Do not touch or look directly at the bulb when fixture is illuminated. Keep flammable materials away from lit bulb.

**WARNING: STRANGULATION HAZARD**

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3 years of age.

**THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.**

**ASSEMBLY AND INSTALLATION**

**SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE FUSE BOX OR CIRCUIT BREAKER PANEL.**

1. Carefully remove all parts from the box and remove all protecting coverings.
2. Insert the dimmable LED Bulb (Not included) into the threaded socket
3. Insert Harp (B) into the Harp Saddle (C).
4. Unscrew the Finial (A) from the Harp (B) and place the desired shade(not included) over the Harp (B).
5. Attach the Finial (A) and tighten to secure the shade.
6. Plug into proper electrical outlet.
7. Dimmer switch on socket to turn the lamp on.
8. Assembly is complete.

**CARE INSTRUCTIONS**

Do not use polishes or cleaners on the fixture.  
Wipe clean with a soft, dry cloth.